




From Quesnel, take the Nazko Highway to Bouchie Lake, turn right onto the Blackwater road. Proceed on Blackwater to 70 km and keep left onto the Batnuni Road. Proceed to 138 km on the Batnuni Rd and turn right onto the Red Road. Follow Red Road for 1.4 Km and turn right. Travel another 1.0 Km and turn right again. Travel another 0.8 km and the road to deactivate is on the right.

FSR Road Deactivation Map

Business Area		Field Team	
Operating Area		Management Unit	
Batnuni			
Road Name	URI	Total Road Length	
FSR Tenure Number		Mapsheet	

Deactivation Method/Access Level	Sta Station	End Station
<Method>	<Access>	<Start Sta> <End Sta>

BCTS Roads - Road State
X-X: Deactivated Road
== Existing Road
== Proposed Road
== Unknown/NULL
Roads (FTEN)
Road Permit
Forest Service Road
Mapsheet Grid 1:20,000
Stream Class
Unknown; UN
INT; NCD
S1; S2; S3; S4; FSF
S5; S6
River or Stream - Definite
River or Stream - Dry/ Indefinite
Contour Line (TRIM)
<Null>
Contour - Index
Contour - Intermediate
Road Station
CLA
Standard Unit Type
Non-Prod Permanent Access
Non-Prod Swamp
Other
WTP
Machine Free Zone
Machine Free Zone
Riparian Management Zone
Wetland
Recreation Area
Transportation Lines 20K (TRIM)
Gravel or Unimproved Road
Stand Level Retention
Stand Level Retention

Operating Areas Block State
Proposed/Planned Cut Block
Regen; Freegrow; NSR
Flooded Land
Marsh
Swamp
Tailing Pond
Lake
Reservoir
Watercourse
OGMA - Legal

0100200300400500

Meters

1:10,000

Date August 26, 2020

Created by RLROBERT

Template Name FSRConstructionMap_11x17L

Coordinate System NAD 1983 BC Environment Albers