FSR Road Deactivation Map

BCTS BC Timber Sales

Business Area	Field Team
Operating Area: Batnuni	Management Unit
Road Name	URI / Total Road Length
FSR Tenure Number	Mapsheet

Deactivation Method/Access Level		Sta Station	End Station
<Method>	<Access>	<Start Sta>	<End Sta>

7674.05
71AL3ZA

POC deactivation

POT deactivation

ACCESS DIRECTIONS:
From Quesnel, proceed west on the Nazko Highway. At 9.5km (Bouchie Lake) turn right onto the Blackwater road. At 70km on the Blackwater Road follow the main road to the left, Batnuni Road. At 132 km turn left onto the Swede Creek FSR. Proceed to 166 km and turn right onto access road. At 172 km keep right and at 173.5 km the road to the right is the one for deactivation.

BCTS Roads - Road State
- Deactivated Road
- Existing Road
- Proposed Road
- Unknown/NULL

Roads (FTEN)
- Road Permit
- Forest Service Road
- Mapsheet Grid 1:20,000

Stream Class
- Unknown; UN
- INT; NCD
- S1; S2; S3; S4; FSF
- S5; S6
- River or Stream - Definite
- River or Stream - Dry/ Indefinite

Contour Line (TRIM)
- <Null>
- Contour - Index
- Contour - Intermediate

- Minor Culvet
- Drain Culvert
- Road Station
- Reach Breaks
- CLA

Standard Unit Type
- Non-Prod Permanent Access
- Non-Prod Swamp
- Other
- WTP
- WTRA
- Machine Free Zone
- Wetland

Transportation Lines 20K (TRIM)
- Gravel or Unimproved Road
- Stand Level Retention
- Stand Level Retention

- Operating Areas

Block State
- Proposed/Planned Cut Block
- Regen; Freegrow; NSR
- Flooded Land
- Marsh
- Swamp
- Tailing Pond
- Lake
- Reservoir
- Watercourse

- OGMA - Legal

0 100 200 300 400 500 Meters

1:10,000

Date August 27, 2020 **Created by** RLROBERT

Template Name FSRConstructionMap_11x17L

Coordinate System NAD 1983 BC Environment Albers